



DIY PROJECT WALL TRANSFORMATION

SUPPLY LIST

- KILZ 2® Latex Primer
- Paint
- Drop Cloth
- 1/4" Nap Paint Roller
- Paint Brush
- Can Key
- Stir Stick
- Damp Cloth
- Tape
- Paint Tray



PRO TIP: Make sure your tape is nice and smooth with no wrinkles or creases in it otherwise paint could leak in.



PRO TIP: Apply primer using a brush first to "cut in" around edges, then use a roller to fill in. That's how the pro's do it.

RESULT



- 1** Wipe down the surface with a damp cloth to remove any dust. Primer and paint won't stick to dust. Allow the surface to dry.
- 2** Tape around baseboards, trim, and moldings.
- 3** Applying primer first is the best way to ensure a perfect finish later. Just as it does with makeup and on cars, primer creates a smooth base that promotes better adhesion and truer color from your topcoat paint.
- 4** Allow 2 hours dry time.
- 5** Apply paint as you did primer, using a brush first to cut in around edges 4 to 6 feet at a time, then use a roller to fill in those sections before moving along.
- 6** Allow 2 hours dry time*, then apply second coat.
- 7** Remove tape prior to paint drying and guess what? You're done. Look how awesome that looks! Camera phone. Insta. #nailedit

*Dark colors and high humidity areas may have extended dry times